











Raisa 3

Instructions



Art. No. 560811

A	1x  75 x 56 x 2.5 cm	F	1x  Ø 42 x 1.8 cm	K	2x 	2	4x  Ø 10 x 90 mm
B	1x  55 x 38 x 1.8 cm	G	1x  55 x 38 cm	L	1x  Ø 15 x 35 cm	3	4x  Ø 40 mm
C	1x  55 x 38 x 1.8 cm	H	1x  Ø 38 cm	M	5x  Ø 15 x 40 cm	4	4x  Ø 4 x 16 mm
D	1x  65 x 45 x 28 cm	I	1x  65 x 40 cm	N	2x  Ø 15 x 55.6 cm		
E	1x  60 x 55 x 1.8 cm	J	1x  Ø 47 x 11 cm	1	8x  Ø 10 x 80 mm		

